




External Level Gauge Diagnosis Manual

V1.0.2

SK Electronic

IR Controller Key Description




- 1: Reset: Press the button to reset the device
- 2: MENU: Open or Close the menu.
- 3: TEST: Display realtime echo wave.
- 4: All of the other button are used to edit the configs

Remarks :

Press "TEST" will enter into wave screen,
Press "TEST" again will enter into diagnosis screen.
Press "MENU" will enter into menu screen,,
Press "MENU" again will enter into diagnosis screen.

LCD Main Screen Description



- ① **P** 485 used as Private Protocol
- M** 485 used as Modbus Protocol

- ② **L** Level Gauge
- B** Interface Gauge

- ③ **4** 4~20mA Output is in malfunction

- ④ **T** Device is disturbed by environment, and reset

- ⑤ **D1** Measure Delay above 10 seconds
- D2** Measure Delay above 20 seconds
- D3** Measure Delay above 30 seconds
- D4** Measure Delay above 40 seconds


- ⑥ **m** **dm** **cm** **mm** LCD Display Height
- %** LCD Display Percentage
- m³** LCD Display Volume
- t** LCD Display Weight

- ⑦ **F2** Measure Fluctuation Index. [1, 10]
Measure is very stable is not showed.
Otherwise the bigger count,
the bigger fluctuation

- ⑧ **Z** System is in recovery

- ⑨ **R** The IR function is disturbed by environment and disabled by system


LCD Debug Screen Description



- ① 3: Current gain
Gain Tpe:
MAIN/1: Auto Gain(Enhanced)
MAIN/2: Fixed Gain
MAIN: Auto Gain, Time Gain, Others
B410: Current dead zone is 410 mm
B/S: B: Current work sensor type is big
S: Current work sensor type is small
- ② 160: Work Frequency, Unit: kHz
1485.0 Current work sound speed, with precision 0.1m/s
1485 Default Sound Speed
1: Work Type

1: Single Sensor Mode
2: Double Sensor Mdoe
3: Temp Calibrate Mode
4: Pipe Calibrate Mode
5: Pipe+Double Sensor Mode
6: Temp + Temp Mode
9: Debug Mode
0: Unknown
- ③ 50: Measure Range Unit: 100mm
20: Calibrate Distance Unit: 100mm
686/E1: In normal state, it represents the current result,
Otherwise it is error code, usually start with 'E'or'F'
1: System feature, Value 1 is normal,
otherwise indicates system is in dead zone
43: Auto calculated blind, Unit: 10mm
- ④ 2356: Signal Strength
324: Noise Strength
0: Filter Error Count
130: Filter Total Count

LCD Wave Screen Description



F160

Current Work Frequency

G10

Current Work Gain。 Min:0,Max:128

D13

When Displayed,it means there 13 cycles delay,
Otherwise there is no delay

MAIN

Flash one time when a measure occurs
MAIN indicates the main sensor is in work,
CAL indicates the calibrate sensor is in work

1850/FE

In normal state, it represents the current result,
Otherwise it is error code, usually start with 'E'or'F'

B442

Real time blind,Unit: mm

B/SE150

B: Current work sensor type is Big;
S: Current work sensor type is Small
E: Envelope Width

①

Auto detected blind

②

Echo position

Menu Description

1. MAIN SENSOR BSC	1.1 SENDING TIME 1.2 FREQUENCY	1.3 BLIND START 1.4 BLIND WINDOW		
2. MAIN SENSOR ADV	2.1 GAIN TYPE 2.2 TGC TYPE 2.3 GAIN 1 2.4 GAIN 2	2.5 HEIGHT UP 2.6 HEIGHT DOWN 2.7 WIDTH UP 2.8 WIDTH DOWN	2.9 FORWARD LEN 2.10 FORWARD WINDOW 2.11 FORWARD THRE 2.12 ENVELOPE	2.13 ECHO AREA CTRL 2.14 ECHO AREA START 2.15 ECHO AREA STOP 2.16 POWER LEVEL 2.17 TANK THICKNESS 2.18 TANK SPEED
3. CAL SENSOR BSC	3.1 SENDING TIME 3.2 FREQUENCY	3.3 BLIND START 3.4 BLIND WINDOW		
4. CAL SENSOR ADV	4.1 GAIN TYPE 4.2 TGC TYPE 4.3 GAIN 1 4.4 GAIN 2	4.5 HEIGHT UP 4.6 HEIGHT DOWN 4.7 WIDTH UP 4.8 WIDTH DOWN	4.9 FORWARD LEN 4.10 FORWARD WINDOW 4.11 FORWARD THRE 4.12 ENVELOPE	4.13 ECHO AREA CTRL 4.14 ECHO AREA START 4.15 ECHO AREA STOP 4.16 POWER LEVEL 4.17 TANK THICKNESS 4.18 TANK SPEED
5. SYSTEM BASIC	5.1 DEFAULT SPEED 5.2 MEASURE RANGE	5.3 OFFSET 5.4 DEAD ZONE	5.5 FILTER LEN 5.6 FILTER FACTOR	5.7 REF SPEED
6. SYSTEM CAL	6.1 DISTANCE 6.2 PERIOD	6.3 HEIGHT 6.4 PIPE CALIB DIST	6.5 LAST CAL SPEED 6.6 UP OFFSET	6.7 DOWN OFFSET 6.8 FACTOR
7. SYSTEM ADV	7.1 DEVICE NO 7.2 LCD DISP TYPE 7.3 LEVEL PRECISION 7.4 LEVEL STRAGEDY	7.5 CIRCLE DETECT 7.6 DEBUG 7.7 RELAY 1 THRE 7.8 RELAY 2 THRE	7.9 SHOW WAVE/PARA 7.10 NO HIGHER THAN 7.11 NO LOWER THAN 7.12 VALIDATE ECHO 7.13 SECOND ECHO REC 7.14 Serial Mode 7.15 Relay Mode 7.16 Level Mode 7.17 Level Zero Jump	7.18 Level Jump Dist 7.19 Level Change Spd 7.20 Crossing Count 7.21 Max Dead Zone 7.22 LCD Disp Content 7.23 Measure Precision 7.24 Tail False Echo Sup 7.25 Primary Work Sensor 7.26 Small Blind Mea Thr 7.27 Gain Limit Lower 7.28 Gain Limit Upper
8. MODE	8.1 SINGLE 8.2 DOUBLE	8.3 PIPE 8.4 PIPE+DOUBLE		
9. DEVICE INFO	9.1 TYPE 9.2 SERIAL NO 9.3 VERSION	9.4 CONTACT 9.5 CHECK PWD		
10. TOOL	10.1 RESET 10.2 Set Debug Mode 10.3 Set Work Mode	10.4 Calibrate Now 10.5 TO FACTORY SETS 10.6 COPY PARAS	10.7 Backup Configs 10.8 Restore Configs	
11. Diagnosis	11.1 Signal Smooth 11.2 System Damp Coef 11.3 View Last Error	Remarks: Red means menu is not locked. Black means menu only visible after system unlocked		

External Level Gauge Error Code

Index	Code	Description	Cause	Solution	Remark
1	FF	Unknown error	Device is breakdown		
2	FE	System enter into blind area	Level is too low		
3	FD	Echo width is too wide	User paras wrong	Contact technical support	
4	FC	Echo width is too narrow	User paras wrong	Contact technical support	
5	FB	System paras wrong	Device is breakdown		
6	FA	Memory error	Device is breakdown		
7	F9	No echo	Tank is empty		
8	F8	Echo height is too high	User paras wrong	Contact technical support	
9	F7	Circular echo is detected	Tank is empty		
10	E0	Echo strength is too weak	Wrong sensor installation	Contact technical support	
11	E1	System blind is too big	Usually occurred when tank is empty or level is high	Adjust "Max Dead Zone" user para	
12	E2	System enter into blind area	There is a lot of silt in the bottom of tank or more than 2 kinds of liquid is detected	Adjust "Signal Smooth" user para	
13	E3	System detects false echo	There is a lot of silt in the bottom of tank or more than 2 kinds of liquid is detected	Adjust "Signal Smooth" user para	

Remark: Error code 0 is a temporary code.